



Calibre Diverter

SUSSEX



Combined wall thickness not to exceed 30mm



Product code

CDIV Diverter

Rough in plumbing

- Prior to installing, calculate the finished wall thickness to ensure the Dress Ring and Handle will fit at the final assembly.
- The Diverter Body is supplied with a plastic cover for protection during Plastering and Tiling.
- Fix a Nogging or a purpose built frame between the Wall Studs.
- Set the Nogging 28 to 35mm back from the front of the stud as shown.
- Using the screws provided, fix the Diverter Body to a the Nogging or purpose built frame.
- All ports are marked on the shoulder of the Diverter body to indicate the appropriate connections.
- Flush all water feed lines. All lines must be free from any dirt and debris before connecting.

NOTE: The Mixed water from the tapware can only be connected to the port marked "Mixed IN"

- After all water connections are made, check water flow is being diverted between Outlet 1 and Outlet 2.
- Check all connections for any water leaks.
- Store remaining parts in a safe place until wall coverings have been completed and final fit-off is required (Dress finishing)

Dress finishing

- Apply the appropriate silicone to seal the Wall around the Mixer Body ensuring the wall is waterproof.
- Fit the Dress Ring onto the Diverter Body until it reaches the Wall covering.
- Fit and align Handle to chosen position and tighten Set screw using the 2.5mm Allen Key provided. (Tighten well)
- Test function to complete installation.

